

Need a Work Permit?

Step 1: Print a CDE form B1-1 application



OR

<https://www.dir.ca.gov/dlse/dlseformB1-1.pdf>

Step 2: Complete the B1-1 application all the way through Employer's Name, Signature and Date.

Please note: **Student, Parent and Employer must all sign** the B1-1 application. Social Security Number is required.

Step 3: Drop off completed application to inbox on Mrs. White's desk in Main Office.

Step 4: Come back to Mrs. White's desk to sign and pick up final work permit before school, at lunch or after school, **2-3 full school days after application drop off.**

Questions: Mrs. Laura White, lwhite5@sandi.net

Mr. Rudy Parra, rparra1@sandi.net